



Overlap Joint Continuation

- 1.) Apply adhesive sealant across end of overlapping extrusion
- 2.) Place the preformed joint sealant over top of the existing extrusion and firmly press into place to ensure complete contact
- 3.) Tool excess adhesive/sealant

Butt Joint Joint Continuation

- 1.) Butter the butt ends of the extrusion with adhesive/sealant
- 2.) Install the preformed joint sealant ensuring the ends butt tightly together
- 3.) Tool the adhesive/sealant of the butt joint flush with the surface