



Joint Intersection (Butt Joint)

- 1.) Apply the vertical preformed joint sealant first
- 2.) Butt the horizontal extrusion to the vertical
- 3.) Butter the ends of the extrusion with adhesive/sealant
- 4.) Slide the horizontal section into place ensuring it butts tightly against the vertical
- 5.) Tool the adhesive/sealant of the butt joint flush with the surface of the preformed joint sealant.