



- Note: - Preformed Joint Sealant should be wrapped tightly around outside corners.
- Sufficient amount of adhesive/sealant must be used to ensure that the extrusion remains in place until the adhesive has cured.
  - If necessary, adhesive tape may be used to hold the extrusion in place until the adhesive/sealant has set up.
  - An alternate solution would be an outside corner butt joint.